

Sola Video 1200

Owners Manual

Light & Motion 300 Cannery Row Monterey, CA 93940, USA

www.lightandmotion.com sales@lightandmotion.com

Your Local Light & Motion Dealer

Standard Warranty

Light & Motion provides a limited warranty to the original purchaser of its products against all defects in original workmanship and material, under normal use and service, for one year from the date of purchase with the following exceptions:

- Batteries are warranted for 90 days.
- Cosmetic discoloration of surfaces.

Light & Motion will not be liable for any further loss, damages, or expenses, including incidental or consequential damages directly or indirectly arising from the sale or use of this product. Products not manufactured by Light & Motion, such as some accessory lenses, are not covered under the Light & Motion warranty. These products are covered by the Terms and Conditions set forth by their respective manufacturers.

Important Information:


- Always lock the control switch of the light when traveling or in storage.
- Never leave your equipment in the rinse bucket. It may be damaged by other equipment.
- Rinse equipment in fresh water after every dive.
- Always store your light fully charged.

Charger Use: 110v - 240v Charge Time: 75% in 60 min, 100% in 150 min


Align guide pin to connect charger.

Battery Status:


Battery status is most accurate after full discharge and full charge cycle.




905-0331-A




Travel and Storage:









Rotate switch to lock/unlock




Brightness Indicator:



Full Brightness Approx. 70 min. Flood, 70 min. Spot



1/2 Brightness Approx. 140 min. Flood, 140 min. Spot



1/4 Brightness Approx. 280 min. Flood, 280 min. Spot